



Extreme Install Basics:

Power Harness

Red /12v

Black/ ground

Yellow/ tap onto Primary ignition...**MUST be done for LOCAL OVER RIDE to operate.**

I/O Harness

Black/ground

Green /attach to black wire on SI harness

Yellow/ **black** on piezo

Other wires/don't use

SI Harness

Red / low or starter side of Primary starter wire

Blue/ high or key side of Primary starter wire

Yellow/ *don't use*

White / 12v

Black/ connect to green wire on I/O harness

Piezo

Red/12v

Black/**yellow** wire on I/O harness